

Juanda International Airport

주안다 국제공항

코 드 : SUB / WARR
도 시 : Surabaya/ 수라바야
국 가 : Indonesia / 인도네시아

기준일: 2008.12.31

◎ 개요

- ▶ 전화 : +62 31-866 75 13, 866 75 14
- ▶ 팩스 : +62 31-866 75 06
- ▶ 홈페이지 : <http://www.angkasapura1.co.id>
- ▶ 이메일 : sub@angkasapura1.co.id

◎ 공항운영자

공항운영주체	PT (Persero) Angkasa Pura I, Juanda International Airport, Branch Office, Surabaya 61253A, East Java.
주요인사	Branch Manager : Bambang Utomo Officer-in-Charge : Mr Wiryatmo Chief of Finance and Materials : Josmet Zein Chief of Administration Division : Sri Rodhiyah Chief of Air Traffic Svcs Division : Mr Sumarsono Chief of Ops & Commercial Division : Harry Utama Chief of Civil Eng & Equipment Div : Heroe Wahjoedi Chief, Electronics & Elec Eng Div : Hendro Kusdiyanto

◎ 시설현황

활주로	Rwy 10/28, 9,843' 3,000 m, width 148' 45 m, asphalt/conc, PCN 83 F/D/X/T
추가활주로	None.
활주로 등화	Rwy 10: single row CL, PAPI. Rwy 28: REIL, CL 2 crossbars, PAPI.
항행시설	ILS (Rwy 10); VOR/DME (Surabaya, ID SBY, 113.1 MHz, Ch 78, S07°22.72' E112°47.67', at airport); NDB (Surabaya, ID SB, 325 kHz, S07°23.17' E112°46.78', at airport; Surabaya, ID WR, S07°21.97' E112°42.15', 099°, 5.1 nm); Radar (0600-2200LT). Frequencies: Twr (0600-2100LT) 118.3, 118.1 MHz; Gnd (0600-1900LT, O/T contact Twr) 118.9 MHz; App (H24) 119.1 MHz; Director 124.0, 118.1 MHz; ATIS 128.2 MHz.
주파수	See Navaids.
인근도시	Surabaya (20 km).
항공기주기	Capacity: 1 A330, 4 A300, 25 B737, 1 F28.
게이트/스텐드	11 gates: 7 domestic, 4 international. 31 stands.
최대 계류장	A300, B747-400.
행거	2: 1 PT Merpati Nusantara Airlines, 1 Indonesian Navy.
표준시간대	UTC+7.
운영시간	0600-2400LT, O/T O/R. Airport of Entry.
소음경감	No procedures in effect.
장애물	No major obstructions or obstacles. Bird hazard.
진입고도	3,000'.

◎ 터미널

터미널	2: 1 domestic, 1 international. 2 cargo.
-----	--